



Changing Strings on Your Harp


1. Make two loops at one end of the string and put the smaller one through the larger.



2. With the smaller loop protruding through the larger, pull on both ends of the string to tighten the knot.




3. When the knot is nearly closed, insert a thicker string or finishing nail through the knot and continue tightening.



4. Tighten the knot and clip off the excess string.




5. Insert the knot vertically down the string hole. On some harps, reinsert the string peg.




Changing Strings on Your Harp

At The Neck


1. Fish the string through the eye from the bottom up and then turn the peg clockwise.



2. Position the string end so that it pinches itself after a half turn.



3. Guide the string towards the inside as you continue to turn.



4. You should reach the appropriate pitch at about 3 complete turns. Clip off excess string.

